



Nothing like Anything



GC200 User Guide

User Guide

Welcome

Thank you for purchasing the Micromax GC200. The Micromax GC200 provides you with the following rich array of exciting features:

- Dual SIM (GSM and CDMA)
- Theft tracker
- VGA Camera
- Audio Player, FM Radio
- Video and Sound Recorder
- Big Speaker
- Memory Card support (up to 8 GB)
- LED torch-3
- Bluetooth

Please read this manual carefully to make the full use of its features.

User Guide

Table of Contents

1 Know Your Phone.....	5	3.8 Format Memory Card	15
1.1 Phone Layout	5	3.9 Applications	15
1.2 Keys and Parts	6	3.10 Organizer	16
1.3 Icons and Indicators	9	3.11 Set your Profile	16
2 Getting Started.....	11	3.12 Use Flashlight	16
2.1 Insert SIM Card	11	4 Phonebook	16
2.2 Insert Memory Card	12	4.1 Add New Contact	17
3 Basic Operations	13	4.2 Options on a Contact	17
3.1 Switch Phone ON/OFF ..	13	4.3 Caller Groups	18
3.2 Make a Call	13	4.4 Send vCard	18
3.3 Answer a Call	14	5 Call Logs	18
3.4 Mute a Call	14	5.1 View Call Logs	18
3.5 Hold a Call Conference ..	14	5.2 Call Log Options	19
3.6 Swap a Call	14	6 Messaging	19
3.7 Manage Your Files	15	6.1 Write Text Messages	19
		6.2 MMS Features	20
		6.3 Broadcast Messages	20

User Guide

6.4 Use Voicemail feature21

7 Multimedia22

7.1 Audio Player.....22

7.2 Video Player.....23

7.3 Video Recorder.....23

7.4 Camera.....24

7.5 Play FM Radio25

7.6 Image Viewer.....27

7.7 Record Sounds.....27

7.8 Schedule FM Recording28

8 Connecting to Networks and Devices.....28

8.1 Set up GPRS Connection28

8.2 Perform WAP Setting.....29

9 Settings30

9.1 Reception Mode.....30

9.2 Phone Settings.....30

9.3 Call Settings.....31

9.4 Reject by SMS:.....32

9.5 Network Settings32

9.6 Safeguard your Phone...32

9.7 Privacy for Data.....32

9.8 Secure your Phone33

9.9 Restore Factory Settings33

10 Safety

PrecautionsError! Bookmark not de

11 Taking Care of

Your DeviceError! Bookmark not de

1 Know Your Phone

1.1 Phone Layout



User Guide

1.2 Keys and Parts

Important keys and parts are listed here for you to use the phone better.

SN	Keys	Function Description
1	Stop Key	Stop playing music of Audio player
2	Previous Key	Previous song in playlist
3	Left soft key (LSK)	Performs functions in lower left display; Enter main menu in standby mode.
4	G1 key	In standby screen press the G1 to enter SIM1 call logs; in dialing mode, press G1 to make a call; answering incoming calls of SIM1
5	Call key	In the standby screen press the Call key to enter the SIM2/UIM Call logs; in dialing mode, press Call key to make the call; answering incoming

User Guide

		calls.
6	Navigation keys	Left: Moving to the left; in the standby screen, access alarm
		Right: Moving to the right; in standby screen, access calendar
		Up: Moving upward; short press during a call to turn up the volume; in the standby screen, write message.
		Down: moving downward; short press during a call to lower the volume; in the standby screen, press to enter shortcuts.
7	Keypad	Input; in menu mode, press the number keys to enter desired functions; in standby screen, long press 2-9 key to speed dial (need setting); long press # key to activate

User Guide

		silent mode; in editing mode, short press  key to switch input method; short press  key to enter the symbol choosing screen; quick press  key repeatedly in dial screen to input * +, p, w.
8	OK key	OK; short press in the standby screen to enter the menu.
9	Play/Pause key	Play/Pause the music
10	Next Key	Next song in playlist
11	Right soft key (RSK)	Performs functions in lower right display; access phonebook.
12	SMS key	Press in the standby screen to enter Messages
13	End key	Hang up a call; reject an incoming call; go back to standby screen; long press to switch on/off the phone.

User Guide

14	Camera lens	For finding a view with the camera.
15	Speaker	You can listen to audio or calls in hands-free mode.
16	LED Flashlight	In standby screen, long press OK key to turn on/off Flashlight. long press 0 key to turn on/off Flashlight;
17	USB jack	Connecting charger, or USB cable for data exchange.
18	Charger jack	For connecting charger
19	Earphone jack	Insert the earphone to answer calls and to listen to music/radio.
20	Receiver	Listen to the voice of the other side when calling.

1.3 Icons and Indicators

Icons

Indicates

Icons

Indicates

User Guide

	Signal strength of SIM1		The current alert type is ring only
	Signal strength of UIM		The current alert type is vibration only
	Unread SMS for SIM1		The current alert type is vibration and ring
	Unread SMS for SIM2/UIM		The current alert type is vibration, then ring
	Missed call for SIM1		The mobile phone is locked
	Missed call for SIM2/UIM		Earphone is plugged in
	Alarm has been set		Current battery capacity
	Bluetooth		Audio player

2 Getting Started

2.1 Insert SIM Card

The GC200 is a Dual SIM mobile phone allowing you to use two SIM (GSM and CDMA) Cards. To insert SIM card(s):

1. Switch off the mobile phone and remove the rear cover and battery.
2. Insert the SIM card correctly in the SIM slot(s) as shown below.



3. Finally, insert the battery and replace the rear cover of the mobile phone.

User Guide

2.2 Insert Memory Card

Use only compatible memory cards approved by Micromax. Incompatible cards may damage the slot or corrupt the data stored in the card.

To insert the memory card:

1. Switch off the phone and remove the rear cover and the battery.
2. Open the memory card slot, and insert the memory card into the slot.



3. Close the memory card slot.
4. Finally, insert the battery and the rear cover of the mobile

phone.

3 Basic Operations

3.1 Switch Phone ON/OFF

To switch ON your phone, press and hold the **End key** for a few seconds.

To turn OFF your phone, press and hold down the **End key** for a few seconds.

3.2 Make a Call

You can make a call in the following ways:

- Enter the desired number in standby mode and press the **Call key**.
- Go to **Menu> Phonebook** and then dial the desired number.
- Just press the **Call key** or the **G1** key to dial the contacts listed in Call logs.

User Guide

- You can also dial a contact from the messages.

3.3 Answer a Call

Press the Answer key to answer a call.

3.4 Mute a Call

Press **Options** and then **Mute** while a call is active.

3.5 Hold a Call Conference

You can talk with more than one person at the same time through call conference.

1. While on a call, go to phonebook and dial a contact. Once the new call gets connected, the first call will be put on hold.
2. After this, press **Options** and then choose **Conference**.

Note: This is network dependent and you may need to contact your network operator for this.

3.6 Swap a Call

1. While on a call, dial a contact. Once the call gets connected, the first call will be put on hold.

User Guide

2. Press **Options** and then choose **Swap**. The active call and the call on hold will be swapped.

3.7 Manage Your Files

Menu > File Manager

You can view and manage your files available in the Phone or memory card from the file Manager. You can rename, view details share, move delete files and so on via the file Manager. You can also format your phone or card memory from here.

3.8 Format Memory Card

Menu > File Manager> Memory Card

After this, press the **Options** and select **Format** to format the memory card.

Warning: All existing files in the memory card will be erased after your format the memory card

3.9 Applications

Menu > Application

The GC200 comes preloaded with Games, text reader, calculator,

User Guide

unit/currency converter, stopwatch to help your with routine tasks.

3.10 Organizer

Menu > Organizer

Your phone helps you organize your tasks with calendar, tasks, alarm clock, world clock etc.

3.11 Set your Profile

Menu > User Profiles

You can choose various profiles based on the need of the hour including headset and Bluetooth profiles.

3.12 Use Flashlight

In standby mode, long press the 0 key to on/off the LED torch.

4 Phonebook

Your phonebook stores all your saved contacts for anytime use. Your

User Guide

phonebook data can be stored in your SIM card or your phone memory.

Menu > Phonebook

4.1 Add New Contact

Menu > Phonebook

To add a new contact:

1. Select **Menu > Phonebook** and press the **Up** navigation key once. Then press the **OK** key.
2. Choose phone or SIM1 SIM2 to store your contact.
3. Enter the desired contact name and number.
4. Press the required keys to save the contact.

Recommendation: You can save a number from the Call logs by highlighting the number and selecting **Save to Phonebook**.

4.2 Options on a Contact

Menu > Phonebook > Options

You can send SMS/MMS, edit, delete, copy, blacklist, send business card, export phonebook and set phonebook preferences and so on from here.

4.3 Caller Groups

Menu > Phonebook > Right navigation key

Define and manage caller groups with special preferences such as ringtone, caller picture etc.

4.4 Send vCard

Menu > Phonebook > Left Soft Key > Send vCard

You can send the contact number of one person to another contact through this feature.

5 Call Logs

5.1 View Call Logs

Menu > Call Logs > Left/Right navigation keys

You can view your call logs for SIM1 and SIM 2.

Press the **Left** or **Right** navigation keys to access the call log tabs, dialed, received, or missed calls:

User Guide

*Tip: You can also directly access the call logs of SIM 1 and SIM 2 by directly pressing the **G** key or the **Call key**.*

5.2 Call Log Options

Pressing **Options** in your Call logs screen gives you a host of options like sending messages, saving to phonebook, blacklist, delete, and even advanced options like viewing call timers, message or GPRS count etc.

6 Messaging

6.1 Write Text Messages

Menu > Messages > SMS

You can compose text messages. Pressing options during/after composing, you can.

- Send the message via SIM 1 or SIM 2.

User Guide

- Insert common symbols to your message.
- Choose input method.
- Use existing text template into the SMS.
- Insert number/name/bookmark into the SMS.
- Save the message for sending at a later time.

6.2 MMS Features

Menu > Messages > MMS

Allows you to write/compose a Multimedia message.

You have these options:

- Fill in the required fields (To, CC, BCC, subject) as desired
- Highlight the **Edit content** line and press **OK** to compose the message
- You can insert symbols and media files, attachments, and so on in your MMS.

6.3 Broadcast Messages

Broadcast message is an information service to all GSM users in a specific location sent by the network operator, such as weather

User Guide

forecast, transportation conditions and so on. You can access this feature via:

Menu > Messages > Broadcast message

You have the following options under this feature:

- **Receive mode:** Choose whether to enable or disable cell broadcast.
- **Read Message:** Read the received message broadcast by the service provider.
- **Languages:** Choose the display language of cell broadcast.
- **Channel Settings:** Set the channel of cell broadcast.

You may need to contact your network operator for the broadcast message channel settings.

6.4 Use Voicemail feature

Menu > Messages> SMS> SMS Settings> Voicemail Server

You can receive SMS alerts regarding your voicemails.

This SMS alert is useful when you divert certain calls based on your call availability setting.

Note: You need to contact your network provider for the voicemail server number.

7 Multimedia

7.1 Audio Player

Menu > Multimedia> Music

The Micromax GC200 comes with an inbuilt music player that plays all your favorite songs stored in the phone memory or T-Flash memory card.

Menu > Multimedia> Music > List

Lists the songs or music files available in the phone or memory card.

Menu > Multimedia> Music > List > Options

You can:

- View details of the selected song.
- Add a song as a ringtone.
- Refresh the song list.

User Guide

- Choose preferences for the audio player.

7.2 Video Player

Menu > Multimedia > Video player

The Video Player plays all your video files stored in the Phone or card memory). The video player allows you to:

- Send current video through MMS or Bluetooth
- Rename the current video file.
- Delete the current video or all files in the list.
- Sort the videos by the methods available.
- Set the storage location for the video

While playing the video, press the **Left key** to pause and **Right key** to stop.

7.3 Video Recorder

Menu > Multimedia > Video Recorder

Press the **OK** Key to start recording.

Pressing **Left Key** allows you to:

- Set relevant parameters for the recorder.
- Set preferences for the video.
- Set white balance for the video.
- Set the different effects for the video.
- Set the storage location for the video file.
- **Restore default:** Restore video settings to default.

7.4 Camera

Menu > Multimedia > Camera:

The built-in camera allows you to take photos and adjust the camera settings. You have the following options:

- View the saved photos.
- Set preferences for the camera.
- Set the size and quality of the image.
- Set white balance of the photo.
- Set the scene mode of photo.
- Set the different effect for display of photo.

User Guide

- Set the storage location for photo.
- Restore camera settings to default.

You can press the number keys to access the individual settings.

7.5 Play FM Radio

Menu > FM radio

You can listen to your favorite FM channels using the inbuilt FM receiver of your phone.

Options > Channel List

List all the current saved channels. Just perform an auto search to fill up this list.

Options > Manual Input

Input the desired channel frequencies manually.

Options > Auto search

Automatically search FM channels and fill up your channel list.

Options > Settings

Select the FM Radio preferences such as background play, loudspeaker, recording format, quality, storage location and so on.

User Guide

Options > Record

Record the currently playing channel. You can also press the Down navigation key to start recording.

Options > Append

Append your current recording with a previous recording to create a combined recording.

Options > File List

View the existing list of recordings.

To Increase/Decrease the volume:

Press the * key to decrease the volume. Press the # key to increase the volume.

To switch between channels:

Press the number keys on your keypad in accordance to the channel list. If this does not work, perform an auto search once.

To start/stop the Radio:

Press the Down key to start/stop the radio or **OK** key to start recording.

7.6 Image Viewer

Menu > Multimedia > Image viewer

Pressing **Left key** on the Image viewer screen allows you to:

- View the picture.
- Print the image via Bluetooth.
- Set the picture browse style such as list or matrix mode.
- Send the present image through MMS or Bluetooth.
- Use the image as wallpaper, screen saver or caller picture.
- Rename the highlighted file.
- Delete the highlighted file.
- Sort the images by desired method.
- Delete all the files from the list.
- Set the storage location for photo.

7.7 Record Sounds

Menu > Multimedia > Sound recorder

User Guide

Pressing **Options** on the Sound Recorder screen gives you these options:

- **New Record:** Begin recording. The recordings will be saved in the Audio folder.
- **List:** List all the recorded files.
- **Settings:** Set some relevant parameters for the sound recorder.

7.8 Schedule FM Recording

Menu > Multimedia > Schedule FM Recording

You can even schedule your FM recording by choosing the recording parameters for the listed channels. You can record up to 4 channels using this feature.

8 Connecting to Networks and Devices

8.1 Set up GPRS Connection

Choose your data accounts for connection on the Internet via GPRS connection. For this you need to set up a data account.

User Guide

1. Go to **Menu> Connectivity> Data Account**.

2. Select from the list of default data accounts listed by your network provider's SIM.

By default, your SIM card comes with data accounts to choose from. If the Data accounts are not listed by default, please contact your network provider for the same.

8.2 Perform WAP Setting

You can do WAP profile setting for displaying web pages. Do this after setting up a data account. Please refer to the previous section, set up GPRS connection for setting up a data account.

1. Go to **Menu> Settings> WAP**.

2. Touch WAP Settings and tap on WAP profiles

3. Set your homepage, bookmarks, input address and so on for your desired web page.

4. Enter or select the details of the profile.

Note: You can perform further WAP preferences via the settings.

9 Settings

Menu > Settings

You can customize your mobile phone to your needs through the settings provided on the phone:

9.1 Reception Mode

Menu > Settings>Reception Mode

Using this feature, you can choose which SIM to use for your calls. You can also set the Flight mode to deactivate calls and SMS.

9.2 Phone Settings

Menu > Settings> Phone Settings

Allows you to set such preferences as shortcuts, time and date, schedule power, language, input method, display settings, dedicated keys, smart dialing and so on.

9.3 Call Settings

Menu> Settings > Call Settings

You can set your call preferences such as :

- **Caller ID:** Hide/unhide caller ID or as set by network.
- **Call Waiting:** If active, incoming calls during another active call will be put on wait.
- **Call Divert:** This feature is network dependent. You may divert incoming calls to another mobile phone or to a voicemail server for later retrieval.
- **Call Barring:** This feature can restrict outgoing and incoming calls selectively. If you need to change the settings or restrict calls, please contact your network operator for the required setting.

9.3.1 Blacklist Numbers:

Menu> Settings > Call Settings > Advanced Settings> Blacklist

This feature blocks a list of contacts as per your choice.

9.4 Reject by SMS:

Send an SMS to the contact automatically after rejecting a call.

9.5 Network Settings

Menu > Settings > Network Settings

Allows you to set the network and associated preferences for SIM1/SIM2.

9.6 Safeguard your Phone

Menu > Settings > Security Settings > Theft Tracker

You can track your phone in case of loss or thefts by activating the Theft Tracker mode and configuring alternate numbers for messages to be received from the unauthorized user. The default password to use this feature is 0000.

9.7 Privacy for Data

Menu > Settings > Security Settings > Data Protect

You can protect your phonebook, messages, call history, and file Manager through this feature.

Note: You can also change the default password to a password of your choice. The default password to use this feature is 0000.

User Guide

9.8 Secure your Phone

Menu > Settings> Security Settings> Phone Lock

Lets you lock your phone via a security password which you can change anytime. The default security code to unlock the phone is 0000.

Note: After you activate the phone lock, you would be asked for a password when you power on your phone next time.

9.9 Restore Factory Settings

Menu > Settings> Restore Factory Settings

Lets you restore your phone settings to the original setting when you purchased the phone:

The default password to use this feature is 0000.

10 Health and Safety Information

Please read the following guidelines regarding the use of your phone. Not following them may be dangerous or illegal.

User Guide

SAR Information

- Your phone is designed not to exceed the limits of emission of radio waves recommended by international guidelines. These guidelines includes safety margins designed to assure the protection of all persons, regardless of age and health.
- SAR (specific absorption rate) is the measurement of body-absorbed RF quantity when the phone is in use. SAR value is ascertained according to the highest RF level generated during laboratory tests.
- The true SAR level during phone usage will be far lower than this level.
- The SAR value of the phone may change depending on factors such as how close you are to a network base station, use of accessories and other enhancements.
- The highest SAR value for use of the device at the head is 1.151 W/kg averaged over 10 gm of human tissue.
- The SAR value may differ depending on national reporting, testing requirements and the network band.

SAR Recommendations

User Guide

- Please keep your calls short and use SMS whenever more convenient. This advice applies especially to children, adolescents and pregnant women
- Prefer to use your cell phone when the signal quality is good.
- People having active medical implants should preferably keep the cell phone at least 15 cm away from the implant.
- Maintain a preferable distance of 15 mm from the device.

Safe Driving

- Do not use the phone while driving. When you have to use the phone, please use the personal hands-free kit.
- Please do not put the phone onto any passenger seat or any place from which it may fall down in case of vehicular collision or emergency braking.

During Flight

- Flight is influenced by interference caused by the phone. It is illegal to use a phone on the airplane. Please turn off your phone or switch to flight mode during a flight.

In Hospitals

User Guide

- Your Phone's radio waves may interfere with the functioning medical devices. Consult a physician or the manufacturer of the medical device to determine whether they are adequately shielded from external Radio Frequency. Switch off your device when regulations posted instruct you to do so.
- Do not carry the wireless device in a breast pocket.
- Turn off the phone if there is any reason to suspect that interference is taking place.

Unsafe Areas

- Please turn off your phone when you are close to a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored.

11 Taking Care of Your Device

Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:

User Guide

- Keep the device dry. If your device gets wet, remove the battery without turning on the device, wipe it with a dry cloth and take it to the service center.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not attempt to open the device other than as instructed in this guide. Repairing the phone by yourself other than our authorized service agents/centers goes against the warranty rules.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not store your device near magnetic fields or allow your device to come in contact with magnetic fields for extended period of time.

User Guide

Battery Recommendations:

- Please put the battery in a well-ventilated place out of direct sunlight. Charge the battery at room temperature range.
- If the time span of the battery after charging becomes much shorter than usual, the battery life is at an end. Replace the battery with a new battery of the same make and specification.
- Do not discard the battery with household trash. Please dispose of used battery according to your local environmental laws and guidelines.
- Use manufacturer approved batteries, chargers, accessories and supplies. Micromax will not be responsible for user's safety when using unapproved batteries or accessories.

Disclaimers

- Micromax will not bear any responsibility for any incompliance with the above mentioned guidelines or improper usage of the mobile phone.
- The content of this manual may vary from the actual content displayed in the mobile phone. In such a case, the later shall govern.

User Guide

- Micromax keeps the right to make modifications to any of the content in this user guide without public announcement or prior notification.
- The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.

Copyrights:

- All rights reserved. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Micromax is strictly prohibited.